
How to disable the battery saver?


XIAOMI

HyperOS 2.0







Click on Phone Settings






































Make sure your app is allowed to start in background





Return to phone setting and select Battery





For Current mode choose either Performance mode or Balanced